

Kramer Electronics, Ltd.



Protocol 3000

Version 1.00 (Full Version)

Contents

1	Protocol 3000 Syntax	1
1.1	Host Message Format	1
1.1.1	Simple Command	1
1.1.2	Command String	1
1.2	Device Message Format	1
1.2.1	Device Long Response	1
1.3	Command Terms	2
1.4	Entering Commands	3
1.5	Command Forms	3
1.6	Command Chaining	3
1.7	Maximum String Length	3
1.8	Backward Support	3
2	Commands	4
2.1	Help Commands	4
2.2	Device Initiated Messages	4
2.3	Result and Error Codes	4
2.4	Basic Routing Commands	5
2.5	Preset Commands	6
2.6	Operation Commands	6
2.7	Audio Parameters Commands	7
2.8	Identification Commands	8
2.9	Network Setting Commands	9
2.10	Machine Information Commands	9
2.11	Advanced Switching Commands	10

Note that “Protocol 3000 compatible” does not imply that a machine includes all of the commands below. Each machine uses a sub-set of Protocol 3000, as per its needs.

1 Protocol 3000 Syntax

1.1 Host Message Format

Start	Address (optional)	Body	Delimiter
#	<i>Destination_id@</i>	Message	CR

1.1.1 Simple Command

Command string with only one command without addressing:

Start	Address (optional)	Body	Delimiter
#		Command SP <i>Parameter_1,Parameter_2,...</i>	CR

1.1.2 Command String

Formal syntax with commands concatenation and addressing:

Start	Address	Body	Delimiter
#	<i>Destination_id@</i>	Command_1 <i>Parameter1_1,Parameter1_2,.../</i> Command_2 <i>Parameter2_1,Parameter2_2,.../</i> Command_3 <i>Parameter3_1,Parameter3_2,.../...</i>	CR

1.2 Device Message Format

Start	Address (optional)	Body	delimiter
~	<i>Sender_id@</i>	Message	CR LF

1.2.1 Device Long Response

Echoing command:

Start	Address (optional)	Body	Delimiter
~	<i>Sender_id@</i>	Command SP [<i>Param1 ,Param2 ...</i>] result	CR LF

CR = Carriage return (ASCII 13 = 0x0D)

LF = Line feed (ASCII 10 = 0x0A)

SP = Space (ASCII 32 = 0x20)

1.3 Command Terms

Command

A sequence of ASCII letters ('A'-'Z', 'a'-'z' and '-').
Command and parameters must be separated by at least one space.

Parameters

A sequence of alphanumeric ASCII characters ('0'-'9', 'A'-'Z', 'a'-'z' and some special characters for specific commands). Parameters are separated by commas.

Message string

Every command entered as part of a message string begins with a **message starting character** and ends with a **message closing character**.

Note: A string can contain more than one command. Commands are separated by a pipe ('| ') character.

Message starting character

'#' – For host command/query
'~' – For machine response

Device address (Optional, for K-NET)

K-NET Device ID followed by '@'

Query sign

'?' follows some commands to define a query request.

All outputs sign

'*' defines all outputs.

Message closing character

CR – For host messages; carriage return (ASCII 13)

CRLF – For machine messages; carriage return (ASCII 13) + line-feed (ASCII 10)

Command chain separator character

When a message string contains more than one command, a pipe ('| ') character separates each command.

Spaces between parameters or command terms are ignored.

1.4 Entering Commands

You can directly enter all commands using a terminal with ASCII communications software, such as HyperTerminal, Hercules, etc. Connect the terminal to the serial, Ethernet, or USB port on the Kramer device. To enter **CR**, press the Enter key. (**LF** is also sent but is ignored by command parser).

For commands sent from some non-Kramer controllers like Crestron, some characters require special coding (such as, /X##). Refer to the controller manual.

1.5 Command Forms

Some commands have short name syntax in addition to long name syntax to allow faster typing. The response is always in long syntax.

1.6 Command Chaining

Multiple commands can be chained in the same string. Each command is delimited by a pipe character ('|'). When chaining commands, enter the **message starting character** and the **message closing character** only once, at the beginning of the string and at the end.

Commands in the string do not execute until the closing character is entered.

A separate response is sent for every command in the chain.

1.7 Maximum String Length

64 characters

1.8 Backward Support

Protocol 2000 is transparently supported by Protocol 3000. You can switch between protocols using a switch protocol command from either platform.

2 Commands

2.1 Help Commands

Command	Syntax	Response
Protocol handshaking	# CR	-Ok CRLF

2.2 Device Initiated Messages

Command	Syntax
Start message	Kramer Electronics LTD. , Device Model Version Software Version

Switcher actions:

Audio-video channel has switched (AFV mode)	AV IN>OUT
Video channel has switched (breakaway mode)	VID IN>OUT
Audio channel has switched (breakaway mode)	AUD IN>OUT

2.3 Result and Error Codes

	Syntax
Command ran successfully, no error.	COMMAND PARAMETERS OK

Protocol Errors:

Syntax error	ERR001
Command not available for this device	ERR002
Parameter is out of range	ERR003
Unauthorized access (command run without the matching login).	ERR004

2.4 Basic Routing Commands

Command	Syntax	Response
Switch audio and video	AV <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ...	AV <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> ... <u>RESULT</u>
Switch video only	VID <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ... Short form: V <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ...	VID <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ... <u>RESULT</u>

Note:

When AFV mode is active, this command also switches audio. If audio is in breakaway mode, the device display mode changes to show the audio connection status.

Switch audio only	AUD <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ... Short form: A <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ...	AUD <u>IN</u> > <u>OUT</u> , <u>IN</u> > <u>OUT</u> , ... <u>RESULT</u>
-------------------	--	---

Note:

When AFV mode is active, this command also switches video.

Read video connection	VID? <u>OUT</u> Short form: V? <u>OUT</u> VID? *	VID <u>IN</u> > <u>OUT</u> VID <u>IN</u> >1, <u>IN</u> >2, ...
Read audio connection	AUD? <u>OUT</u> Short form: A? <u>OUT</u> AUD? *	AUD <u>IN</u> > <u>OUT</u> AUD <u>IN</u> >1, <u>IN</u> >2, ...
Reset video and audio connections	AV-RST	AV-RST <u>RESULT</u>

Parameter Description:

IN = Input number or '0' to disconnect output.

'>' = Connection character between in and out parameters.

OUT = Output number or '*' for all outputs.

Examples:

Switch video and audio input 3 to output 7	#AV 3>7 <u>CR</u>	-AV 3>7 OK <u>CRLF</u>
Switch video input 2 to output 4	#V 2>4 <u>CR</u>	-VID 2>4 OK <u>CRLF</u>
Switch video input 4 to output 2 in machine number 6	#6@VID 4>2 <u>CR</u>	-6@VID 4>2 OK <u>CRLF</u>
Disconnect video and audio output 4	#AV 0>4 <u>CR</u>	-AV 0>4 OK <u>CRLF</u>
Switch video input 3 to all outputs	#V 3>* <u>CR</u>	-VID 3>* OK <u>CRLF</u>
Chaining multiple commands	#AV 1>* V 3>4, 2>2, 2>1, 0>2 V 3>9 A 0>1 V? * <u>CR</u> 1. Switch audio and video from input 1 to all outputs. 2. Switch video input 3 to output 4, video input 2 to output 2, video input 2 to output 1 and disconnect video output 2. 3. Switch video input 3 to output 9 (non-existent). 4. Disconnect audio output 1. 5. Get status of all video links. Command processing begins after entering <u>CR</u> . A response is sent for each command after processing.	-AV 1>* OK <u>CRLF</u> -VID 3>4, 2>2, 2>1, 0>2 OK <u>CRLF</u> -VID <u>ERR003</u> <u>CRLF</u> -AUD 0>1 OK <u>CRLF</u> -VID 2>1, 0>2, 1>3, 3>4 <u>CRLF</u>

2.5 Preset Commands

Command	Syntax	Response
Store current connections to preset	PRST-STO <u>PRESET</u> Short form: PSTO <u>PRESET</u>	PRST-STO <u>PRESET</u> <u>RESULT</u>
Recall saved preset	PRST-RCL <u>PRESET</u> Short form: PRCL <u>PRESET</u>	PRST-RCL <u>PRESET</u> <u>RESULT</u>
Delete saved preset	PRST-DEL <u>PRESET</u> Short form: PDEL <u>PRESET</u>	PRST-DEL <u>PRESET</u> <u>RESULT</u>
Read video connections from saved preset	PRST-VID? <u>PRESET</u> <u>OUT</u> Short form: PVID? <u>PRESET</u> <u>OUT</u> PRST-VID? <u>PRESET</u> , *	PRST-VID <u>PRESET</u> , <u>IN</u> - <u>OUT</u> PRST-VID <u>PRESET</u> , <u>IN</u> -1, <u>IN</u> -2,...
Read audio connections from saved preset	PRST-AUD? <u>PRESET</u> <u>OUT</u> Short form: PAUD? <u>PRESET</u> <u>OUT</u> PRST-AUD? <u>PRESET</u> , *	PRST-AUD <u>PRESET</u> , <u>IN</u> - <u>OUT</u> PRST-AUD <u>PRESET</u> , <u>IN</u> -1, <u>IN</u> -2,...
Read saved presets list	PRST-LST? Short form: PLST?	PRST-LST <u>PRESET</u> , <u>PRESET</u> , ...

Parameter Description:

PRESET = Preset number.

OUT = Output in preset to display, '*' for all.

Examples:

Store current audio and video connections to preset 5	#PRST-STR 5 <u>CR</u>	~PRST-STR 5 OK <u>CRLF</u>
Recall audio and video connections from preset 3	#PRCL 3 <u>CR</u>	~PRST-RCL 3 OK <u>CRLF</u>
Show source of video output 2 from preset 3	#PRST-VID? 3,2 <u>CR</u>	~PRST-VID 3: 4>2 <u>CRLF</u>

2.6 Operation Commands

Command	Syntax	Response
Lock front panel	LOCK-FP <u>LOCK-MODE</u> Short form: LCK <u>LOCK-MODE</u>	LOCK-FP <u>LOCK-MODE</u> <u>RESULT</u>
Get front panel locking state	LOCK-FP?	LOCK-FP <u>LOCK-MODE</u>

Parameter Description:

LOCK-MODE = Front panel locking state:

'0' or 'off' to unlock front panel buttons

'1' or 'on' to lock front panel buttons

Reset device	RESET	RESET OK
Switch to protocol 2000*	P2000	P2000 OK

* Protocol 2000 has a command to switch back to ASCII protocol (like Protocol 3000)

2.7 Audio Parameters Commands

Command	Syntax	Response
Set simple audio volume	VOLUME <u>VOLUME</u> Short form: VOL <u>VOLUME</u>	VOLUME <u>VOLUME</u> <u>RESULT</u>
Increase/decrease simple audio volume	VOLUME <u>+/-</u> Short form: VOL <u>+/-</u>	VOLUME <u>+/-</u> <u>RESULT</u>
Read simple audio level	VOLUME? Short form: VOL?	VOLUME <u>VOLUME</u>
Set audio level in specific amplifier stage.	AUD-LVL <u>STAGE</u> <u>CHANNEL</u> <u>VOLUME</u> Short form: ADL <u>STAGE</u> <u>CHANNEL</u> <u>VOLUME</u>	AUD-LVL <u>STAGE</u> <u>CHANNEL</u> <u>VOLUME</u> <u>RESULT</u>
Read audio volume level	AUD-LVL? <u>STAGE</u> <u>CHANNEL</u> Short form: ADL? <u>STAGE</u>	AUD-LVL <u>STAGE</u> <u>CHANNEL</u> <u>VOLUME</u>

Advanced commands for controlling each stage of audio amplification:

Set audio bass level	BASS <u>CHANNEL</u> <u>BASS</u> Short form: ADB <u>CHANNEL</u> <u>BASS</u>	BASS <u>CHANNEL</u> <u>BASS</u> <u>RESULT</u>
Read audio bass level	BASS? <u>CHANNEL</u> Short form: ADB? <u>CHANNEL</u>	BASS <u>CHANNEL</u> <u>BASS</u>
Set audio treble level	TREBLE <u>CHANNEL</u> <u>TREBLE</u> Short form: ADT <u>CHANNEL</u> <u>TREBLE</u>	TREBLE <u>CHANNEL</u> <u>TREBLE</u> <u>RESULT</u>
Read audio treble	TREBLE? <u>CHANNEL</u> Short form: ADT? <u>CHANNEL</u>	TREBLE <u>CHANNEL</u> <u>TREBLE</u>
Set audio midrange	MIDRANGE <u>CHANNEL</u> <u>MID_RANGE</u> Short form: ADM <u>CHANNEL</u> <u>MID_RANGE</u>	MIDRANGE <u>CHANNEL</u> <u>MID_RANGE</u> <u>RESULT</u>
Read audio midrange	MIDRANGE? <u>CHANNEL</u> Short form: ADM? <u>CHANNEL</u>	MIDRANGE <u>CHANNEL</u> <u>MID_RANGE</u>
Set audio loudness	LOUDNESS <u>CHANNEL</u> <u>LOUDNESS</u> Short form: ADS <u>CHANNEL</u> <u>LOUDNESS</u>	LOUDNESS <u>CHANNEL</u> <u>LOUDNESS</u> <u>RESULT</u>
Read audio loudness	LOUDNESS? <u>CHANNEL</u> Short form: ADS? <u>CHANNEL</u>	LOUDNESS <u>CHANNEL</u> <u>LOUDNESS</u>
Set audio mix	MIX <u>MIX-MODE</u>	MIX <u>MIX-MODE</u> <u>RESULT</u>
Read audio mix	MIX?	MIX <u>MIX-MODE</u>
Mute audio	MUTE <u>MUTE-MODE</u>	MUTE <u>MUTE-MODE</u> <u>RESULT</u>
Read audio mute state	MUTE?	MUTE <u>MUTE-MODE</u>
Set stereo mode	STEREO <u>STEREO-MODE</u>	STEREO <u>STEREO-MODE</u> <u>RESULT</u>
Read stereo mode	STEREO?	STEREO <u>STEREO-MODE</u>
Set balance mode	BALANCE <u>OUT-CHANNEL</u> <u>BALANCE-LEVEL</u>	BALANCE <u>OUT-CHANNEL</u> <u>BALANCE-LEVEL</u> <u>RESULT</u>
Read balance mode	BALANCE? <u>OUT-CHANNEL</u>	BALANCE <u>OUT-CHANNEL</u> <u>BALANCE-LEVEL</u>

Parameter Description:**STAGE** = 'IN', 'OUT'

or

Numeric value of present audio processing stage. For example: '0' for input level, '1' for pre-amplifier, '2' for amplifier (OUT) etc.

CHANNEL = Input or Output #**VOLUME** / **BASS** / **TREBLE** / **MID_RANGE** = Audio parameter in Kramer units, minus sign precedes negative values.

++ increase current value,

-- decrease current value.

MIX =

'0' or 'OFF'

'1' or 'ON'

2.8 Identification Commands

Command	Syntax	Response
Protocol handshaking	# CR	~OK CRLF
Read device model	MODEL?	MODEL MACHINE_MODEL
Read device serial number	SN?	SN SERIAL_NUMBER
Read device firmware version	VERSION?	VERSION MAJOR MINOR BUILD REVISION
Set machine name	NAME MACHINE_NAME	NAME MACHINE_NAME RESULT
Read machine name	NAME?	NAME MACHINE_NAME
Reset machine name to factory default*	NAME-RST	NAME-RST MACHINE_FACTORY_NAME RESULT

***Note:** The machine name is not the same as the model name. The machine name is used to identify a specific machine or a network in use (with DNS feature on).

MACHINE_NAME = Up to 14 alphanumeric chars.

* **Machine factory name** = Model name + last 4 digits from serial number.

Set machine ID number	MACH-NUM MACHINE_NUMBER	MACH-NUM OLD_MACHINE_NUMBER NEW_MACHINE_NUMBER RESULT
-----------------------	--------------------------------	--

* A response is sent after the machine number was changed. The response with the header is:

NEW_MACHINE_NUMBER @MACH-NUM **OLD_MACHINE_NUMBER** **NEW_MACHINE_NUMBER** OK

2.9 Network Setting Commands

Command	Syntax	Response
Set IP address	NET-IP <u>IP_ADDRESS</u> Short form: NTIP	NET-IP <u>IP_ADDRESS</u> <u>RESULT</u>
Read IP address	NET-IP? Short form: NTIP?	NET-IP <u>IP_ADDRESS</u>
Read MAC address	NET-MAC? Short form: NTMC	NET-MAC <u>MAC_ADDRESS</u>
Set subnet mask	NET-MASK <u>SUBNET_MASK</u> Short form: NTMSK	NET-MASK <u>SUBNET_MASK</u> <u>RESULT</u>
Read subnet mask	NET-MASK? Short form: NTMSK?	NET-MASK <u>SUBNET_MASK</u>
Set gateway address	NET-GATE <u>GATEWAY_ADDRESS</u> Short form: NTGT	NET-GATE <u>GATEWAY_ADDRESS</u> <u>RESULT</u>
Read subnet mask	NET-GATE? Short form: NTGT?	NET-GATE <u>GATEWAY_ADDRESS</u>
Set DHCP mode	NET-DHCP <u>DHCP_MODE</u> Short form: NTDH	NET-DHCP <u>DHCP_MODE</u> <u>RESULT</u>
Read subnet mask	NET-DHCP? Short form: NTDH?	NET-DHCP <u>DHCP_MODE</u>

DHCP_MODE =

'0' – Don't use DHCP (Use IP set by factory or IP set command).

'1' – Try to use DHCP, if unavailable use IP as above.

Change protocol Ethernet port	ETH-PORT <u>PROTOCOL</u> <u>PORT</u> Short form: ETHP	ETH-PORT <u>PROTOCOL</u> <u>PORT</u> <u>RESULT</u>
Read protocol Ethernet port	ETH-PORT? <u>PROTOCOL</u> Short form: ETHP?	ETH-PORT <u>PROTOCOL</u> <u>PORT</u>

PROTOCOL = TCP/UDP (transport layer protocol)

PORT = Ethernet port that accepts Protocol 3000 commands

1-65535 = User defined port

0 - Reset port to factory default (50000 for UDP, 5000 for TCP)

2.10 Machine Information Commands

Command	Syntax	Response
Set device time and date	TIME <u>DATE_TIME</u>	TIME <u>DATE_TIME</u> <u>RESULT</u>
Read device time and date	TIME?	TIME? <u>DATE_TIME</u>
Note: Time setting commands require administrator authorization.		
Read in/out count	INFO-IO?	INFO-IO: IN <u>INPUTS_COUNT</u> , OUT <u>OUTPUTS_COUNT</u>
Read max preset count	INFO-PRST?	INFO-PRST: VID <u>PRESET_VIDEO_COUNT</u> , AUD <u>PRESET_AUDIO_COUNT</u>
Execute firmware upgrade*	UPGRADE	UPGRADE OK

Firmware usually uploads to a device via a command like LDFW. The device may need to be reset to complete the process.

Command	Syntax	Response
Reset to factory default configuration	FACTORY	FACTORY <u>RESULT</u>

2.11 Advanced Switching Commands

Command	Syntax	Response
Set audio follow video mode	AFV <u>AFV-MODE</u>	AFV <u>AFV-MODE</u> <u>RESULT</u>

Note: This command affects the device front-panel mode and AUD/VID command.

Read audio follow video mode	AFV?	AFV <u>AFV-MODE</u>
------------------------------	------	---------------------

AFV-MODE = Front panel AFV mode

'0' or 'afv' sets front panel switching buttons to audio-follow-video state.

'1' or 'brk' sets front panel switching buttons to their previous audio state.